



VOLA 1611, 1621, 1641T8  
VOLA 1671, 1671-HT2

Fitting instruction  
Montageanleitung  
Monteringsvejledning  
Monteringsvægledning  
Montage hanleiding  
Manuel de montage


| Data                                                                                               | Bar:    | 1    | 2    | 3    | 4    | 5    |
|----------------------------------------------------------------------------------------------------|---------|------|------|------|------|------|
| 1611/1621                                                                                          | l/min   | 13.4 | 18.9 | 23.2 | 26.8 | 30.0 |
|                                                                                                    | Gal/min | 3.5  | 5.0  | 6.1  | 7.1  | 7.9  |
| 1641                                                                                               | l/min   | 11.4 | 16.2 | 19.8 | 22.9 | 25.6 |
|                                                                                                    | Gal/min | 3.0  | 4.3  | 5.3  | 6.1  | 6.8  |
| 1641 - T2                                                                                          | l/min   | 6.6  | 9.4  | 11.5 | 13.3 | 14.8 |
|                                                                                                    | Gal/min | 1.74 | 2.5  | 3.0  | 3.5  | 3.9  |
| 1671 - T2<br>1671-HT2                                                                              | l/min   | 9.9  | 14.0 | 17.2 | 19.9 | 22.2 |
|                                                                                                    | Gal/min | 2.6  | 3.7  | 4.5  | 5.3  | 5.9  |
|  Max. 65°C. 150°F |         |      |      |      |      |      |




1611: A    1621: B








1641T8:







1671:



1671-HT2:







# VOLA T2






VOLA A/S • Lunavej 2 • DK-8700 Horsens • Tel. +45 70 23 55 00  
Fax +45 70 23 55 11 • [sales@vola.dk](mailto:sales@vola.dk) • [www.vola.com](http://www.vola.com)

vola®

VOLA T2





**vola**

Lunavej 2  
DK-8700 Horsens  
Tlf : + 45 7023 5500  
sales@vola.com  
www.vola.com


**VOLA 1671**

Date  
Jan. 96


Rev.  
1

Sheet  
SB 51

T2V:



T2:



vola

Lunavej 2  
DK-8700 Horsens  
Tlf : + 45 7023 5500  
sales@vola.com  
www.vola.com

## VOLA T2V & T2

Date  
Sep. 07

Rev.  
1

Sheet  
SB 40